CX-3 FLIGHT COMPUTER
QUICK START GUIDE

ACCESS THE COMPLETE USER'S GUIDE ONLINE
asa2fly.com/CX3

GETTING STARTED

The CX-3 uses 4 AAA batteries (included). Insert batteries by removing the entire back cover of the flight computer. Find a ridge at bottom center; lift up to remove battery cover. Install 4 batteries with correct polarity as depicted within battery compartment. Snap cover back into place.

ON/OFF/ENTER

Press to turn the CX-3 on, hold for 3 seconds to turn the CX-3 off. Note that after 10 minutes of inactivity the CX-3 screen will automatically turn off to conserve battery; wake by pressing the ON button. This same button is used to select highlighted menu items and enter input.

- The CX-3 is authorized and acceptable for use during FAA and Canadian Knowledge Exams, per Airman Certification Standards (ACS), Advisory Circular 60-11, and FAA Order 8080.6.

- All memory is erased by removing and reinstalling the batteries. NOTE: This also resets clock settings.

Aviation Supplies & Academics, Inc.
817 Walbridge Street | Kalamazoo, Michigan 49007
asa2fly.com | 425-235-1500

Copyright © 2017 Aviation Supplies & Academics, Inc.

CX-3 FLIGHT COMPUTER

QUICK START GUIDE

0 1 2 3 4 5 6 7 8 9

Numeric keys for entering numbers.

÷ x — + Standard arithmetic operators.

FLT PLAN TIMER CALC W/B Select each of the 5 main menus.

Use to navigate through the menu structure.

Turn CX-3 ON/OFF. Select highlighted menu item, or enter current input line when function is requesting input.

Favorites, sets a saved function for easy recall.

BACK Changes display to the previous menu.

SET Use to access the CX-3's preferences settings (backlighting, theme, time set, units, etc.)

M Memory function for saving numbers.

SET UNIT Sets the current units for a given function.

CONV UNIT Converts the current value into another unit.

C Clears current input line. In calculator mode, clears the math completely.

BKSP Deletes the last entered value.

: Separates hours from minutes and minutes from seconds on time inputs. For example: 2 hrs, 38 minutes and 45 seconds will display as 02:38:45.

+/− Changes sign (positive or negative) of current input line.

. Decimal point.

√ Activates the square root function.

= Completes the calculation.

COMPLETE USER'S GUIDE ONLINE asa2fly.com/CX3