

Zero Gravity Outdoor Recliner User Manual



Safety Guidelines

- Maximum weight capacity: 275 lbs (125 kg)
 - Only use on a firm, level surface. All legs must stay in contact with the ground.
 - Never use without the plastic feet, or with unsecured armrests or leg hinges.
 - Keep hands clear of moving parts during adjustments.
 - Children must be supervised by an adult while using the lounger.
 - Read all instructions before use.
- ▲ Warning: Plastic bags can cause suffocation. Keep away from babies and children.**

Care & Maintenance

Cleaning:

- Use mild soap and water. Rinse thoroughly and dry completely.
- Avoid using bleach, acids, solvents, or abrasive cleaners. Always spot test first.

Material Notes:

- Constructed from high-quality steel for durability.
- Over time, corrosion may occur, especially if exposed to weather.
- Occasionally drain water from inside the frame to avoid rust stains.
- If paint chips or scratches appear, remove surface rust and apply touch-up paint.

Storage Recommendations:

- When not in use (especially in winter), store indoors or under a suitable cover.
- Always clean and dry the lounger before storage.

Assembly Instructions

1. Unpack and Prepare

- Remove the lounger from its packaging. Place the rear leg of the lounger on the ground and hold it upright (**see Fig. A**).

2. Unfold the Chair

- Hold the backrest tube with one hand.
- With your other hand, press outward and downward on the armrest.
- This motion will cause the lounger to unfold (**see Figs. B & C**).

▲ Caution: Keep fingers away from moving parts to avoid pinching or injury.

3. Lock the Backrest into Position

- Place one foot on the rear leg.
- Slide the backrest fully back, then forward into the most upright position.
- Check that the back leg hinge and bracket are properly positioned (**see Fig. D**).

▲ Do not use the lounger unless all parts are securely in place.

4. Prepare the Front Leg Rest

- Ensure the front leg rest is upright and nearly touching the ground (**see Fig. E**).
- Sit down carefully, then recline by holding the front of the armrests and slowly leaning back.
- Adjust to the desired position.

5. Lock the Reclined Position

- Pull the locking lever as shown in **Figs. F & G** to secure the position.
- To unlock, simply pull the locking lever.


6. Return to Upright Position

- With both hands on the front of the armrests, lean forward until the chair returns upright (**see Fig. H**).

7. Folding the Lounger

- Reverse Steps 1–3 to fold.

▲ Take care not to trap fingers in moving parts.



8. Cup & Phone Holder Installation

- Remove the holder from the packaging (**see Fig. I**).
- Position it between the two feet of the lounger and secure it tightly (**see Fig. J**).

